

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

OPERATOR AND ORGANIZATIONAL MAINTENANCE  
REPAIR PARTS AND SPECIAL TOOLS LIST  
FOR  
PISTOL, CALIBER .45, AUTOMATIC, M1911A1  
(NATIONAL MATCH) WITH ADJUSTABLE REAR SIGHT

HEADQUARTERS, DEPARTMENT OF THE ARMY  
Washington, D.C. 29 February 1968

This manual is current as of 14 February 1968

Page

SECTION I.	INTRODUCTION .....	1
II.	BASIC ISSUE ITEMS LIST .....	4
III.	MAINTENANCE AND OPERATING SUPPLIES .....	6
IV.	REPAIR PARTS	
	Repair Parts For:	
	Major groups and assemblies .....	7
	Slide Group .....	7
	Receiver Group .....	8
V.	SPECIAL TOOLS AND EQUIPMENT .....	10
VI.	INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER	
	CROSS-REFERENCE TO FIGURE AND ITEM NUMBER .....	10

**SECTION I  
INTRODUCTION**

**1. Scope**

This manual lists basic issue items, repair parts, special tools and equipment required for the performance of organizational maintenance of the M1911A1 Pistol (National Match).

**2. General**

The Basic Issue Items, Repair Parts and Special Tools List are divided into the following sections:

*a. Basic Issue Items-Section II.* A list of items which accompany the M1911A1 Pistol (National Match)

and are required by the operator for installation, operation, or maintenance.

*b. Maintenance and Operating Supplies- Section III.* A listing of maintenance and operating supplies required for initial operation.

*c. Prescribed Load Allowance (PLA).* Not applicable.

*d. Repair Parts-Section IV.* A list of repair parts authorized for the performance of maintenance at the organizational level, in figure and item number sequence.

*e. Special Tools and Equipment-Section V.* A list of special tools authorized for the per-

\* This manual supersedes TM 9-1005-211-12p/1, 22 January 1964.

This copy is a reprint which includes current pages from Change 1.

formance of maintenance at the organizational level.

f. *Federal Stock Number and Reference Number Index-Section VI.* A list of Federal stock numbers in ascending numerical sequence, followed by a list of reference numbers appearing in all the listings, in ascending alpha-numeric sequence, cross referenced to the illustration figure number and item number.

### 3. Explanation of Columns

The following provides an explanation of columns in the tabular lists in Sections II, IV, and V.

a. *Source, Maintenance and Recoverability Codes (SMR).*

(1) *Source Code.* Indicates the selection status and source for the listed item. Source codes are:

<i>Code</i>	<i>Explanation</i>
X1	Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of next higher assembly or component.
P	Applied to repair parts which are stocked in or supplied from Army supply system.

(2) *Maintenance Code.* Indicates the lowest category of maintenance authorized to install the listed item. The maintenance level codes are:

<i>Code</i>	<i>Explanation</i>
C	Operator/crew
0	Organizational Maintenance

(3) *Recoverability Code.* Indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable Recoverability code is:

<i>Code</i>	<i>Explanation</i>
R	Applied to repair parts and assemblies which are economically repairable and are furnished by supply on an ex-change basis.

b. *Federal Stock Number.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description.* Indicates the Federal item name and any additional description of the

item required. The abbreviation "w/e" when used as a part of the nomenclature indicates the Federal stock number includes all armament, equipment, accessories, and repair parts issued with the item. A part number or other reference number is followed by the applicable five-digit Federal supply code for manufacturer in parentheses.

d. *Unit of Measure (U/M).* A 2 character alphabetic abbreviation indicating the amount or quantity of the item, upon which the allowances are based, e.g., ft, ea, pr, etc.

e. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in an assembly or group.

f. *Quantity Furnished with the Equipment.* Indicates the quantity of an item furnished with the equipment (BILL only).

g. *15-Day Organizational Maintenance Allowances.* Indicates the total quantity of an item required to be on hand and necessary for maintenance of the equipment. Items to be requisitioned, as required, are indicated by an asterisk.

h. *Illustration.*

(1) *Figure Number.* Indicates the figure number of the illustration in which the item is shown.

(2) *Item Number.* Indicates the callout number used to reference the item in the illustration.

### 4. Explanation of Columns in the Tabular List of Maintenance and Operating Supplies, Section III

a. *Component Application, Column 1.* Identifies the component application of each maintenance or operating supply item.

b. *Federal Stock Number, Column 2.* Indicates the Federal stock number assigned to the item and will be used for requisitioning purposes.

c. *Description, Column 3.* Indicates the item name and brief description.

d. *Quantity Required for Initial Operation, Column 4.* Indicates the quantity of each maintenance or operating supply item required for initial operation of the equipment (M & 0 supplies only).

CHANGE

No. 1



HEADQUARTERS  
DEPARTMENT OF THE ARMY  
WASHINGTON, D.C., 28 November 1972

**Operator and Organizational Maintenance  
Repair Parts and Special Tools List  
for  
PISTOL, CALIBER .45, AUTOMATIC, M1911AI  
(NATIONAL MATCH) WITH ADJUSTABLE REAR SIGHT**

TM 9-1005-211-12P, 29 February 1968, is changed as follows:

Page 1. Paragraph 1 is changed as follows:

**1. Scope**

This manual lists basic issue items, items troop installed or authorized, repair parts and special tools required by the crew/operator for operation and required for the performance of organizational maintenance of the M1911AI Pistol (National Match). One cartridge magazine is furnished as a component item with each weapon (1, fig 3).

Paragraph 2 is changed as follows:

**2. General**

This basic issue items, items troop installed or authorized, repair parts and special tools list is divided into the following sections:

*a. Basic Issue Items List.* Not applicable.

*b. Items Troop Installed or Authorized List- Section II.* A list, in alphabetical sequence, of items required by the operator for sustained operation of the end item. These discretionary items will be requisitioned by the unit in accordance with its mission requirements. They may accompany the end item, but are not subject to be turned in with it.

*c. Repair Parts List-Section IV.* A list of repair parts authorized at the organizational level for the performance of maintenance, with the parts listed in figure and item number sequence. The illustrations also include parts which must be removed for replacement of authorized parts.

*d. Special Tools List-Section V.* A list of special tools, test and support equipment authorized for the performance of maintenance at the organizational level.

*e. Federal Stock Number and Reference Number Index-Section VI.* A list, in ascending numerical sequence, of all Federal stock numbers appearing in the listings, followed by a list, in alphameric sequence, of all reference numbers appearing in the listings. Federal stock numbers are cross-referenced to each illustration figure and item number appearance.

Page 2 Delete paragraph 2f.

Paragraphs 3c through f are changed as follows:

*c. Description.* Indicates the Federal item name and a minimum description required to identify the item. The last line indicates the reference number followed by the applicable Federal supply code for manufacturer (FSCM) in parentheses. The FSCM is used as an element in item identification to designate manufacturer, distributor, or Government agency, etc., and is identified in SB 708-42.

*d. Unit of Measure (U/M).* Indicates the standard or basic quantity by which the listed item is used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation, e.g., ea, in, pr, etc., and is the basis used to indicate quantities. When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

e. *Quantity Authorized (Items Troop Installed or Authorized Only)*. Indicates the quantity of the item authorized to be used with the equipment.

f. *Quantity Incorporated in Unit*. Indicates the quantity of the item used in that functional

group/assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, e.g., shims, spacers, etc.  
Paragraph 4. Deleted

Page 3. Add the following after paragraph 5b.

*Expendable and Consumable Supplies*

FSN	Description	Symbol
6850-965-2332	CARBON REMOVING COMPOUND: (5 gal pail) P-C-111 (81348)	
6850-224-6657	CLEANING COMPOUND, RIFLE BORE: (8 oz can) MIL-C-372 (81349)	RBC
6850-281-1985	DRY CLEANING SOLVENT: (1 gal can) P-D-680 (81348)	SD
9150-273-2389	LUBRICATING OIL, GENERAL PURPOSE: (4 oz can) V V-L-800 (81348)	PL-S
9150-292-9689	LUBRICATING OIL, WEAPONS: for below zero operations (1 qt can) MIILL-14107 (81349)	LAW
7920-205-1711	RAG, WIPING: cotton (50 lb bale) DDD-R-30, class 2, grade B (81348)	
1005-288-3565	SWAB, SMALL ARMS CLEANING: cotton 2-1/2 sq (1,000 in pkg) 5019316 (19204)	

Paragraph 9. Change last sentence to read: "Reports should be submitted on DA Form 2028 (Recommended Changes to Publications) and forwarded direct to

Commander, US Army Weapons Command, ATTN: AMSWEMAS-SP, Rock Island, IL 61201.

Page 4. Section II is changed as follows:

**Section II. ITEMS TROOP INSTALLED OR AUTHORIZED LIST**

(1) Federal Stock No.	(2) Description  Reference Number & Mfr. Code	(3) Unit of meas	(4) Qty auth
1005-550-4036	BRUSH, CLEANING, SMALL ARMS: M5 BORE 5504036 (19204)	EA	1
1005-556-4102	ROD, CLEANING, SMALL ARMS: M4 5564102 (19204)	EA	1

Page 6, section III. Deleted