

Instruction Manual



Romak – 3 Dragunov 7.62x54R

WARNING:

Before using this firearm, read carefully and follow these instructions.

This instruction manual should always accompany the firearm and be transferred with it upon change of ownership.

Safety Guidelines

For Proper Operation and Handling of Your Dragunov Rifle.

1. Understand and follow all basic firearm rules of safe handling.
2. Keep the muzzle of your firearm pointed in a safe direction.
3. Keep firearm unloaded when not in use.
4. Be absolutely certain of your target and the backstop before proceeding to fire (Remember before pulling the trigger that this is a high power, long range weapon).
5. Before loading your firearm, examine the bore to make certain it is unobstructed. Firing a gun with any obstruction in the bore or even a heavy coating of oil or drops of water can cause the barrel to rupture upon firing, causing serious injury to the shooter and bystanders.
6. Never exclusively rely on your gun's safety. Please exercise good judgement.
7. Don't shoot at a hard surface or at water. A bullet may ricochet and travel in unpredictable directions with considerable velocity causing injury and damage to property.
8. Never handle a firearm without checking to make sure that it is unloaded.
9. In case of failure to fire, keep muzzle pointed in a safe direction for at least 30 seconds. After 30 seconds, remove the magazine and slowly open the action to retrieve the cartridge. Then properly dispose of the mis-fired round.
10. Always use eye and ear protection.

Loading & Operation

Loading Your Dragunov

1. Place bullet in the center of the magazine and depress downward (Repeat until the mag is full).
2. When the mag is loaded, (keeping the weapon pointed in a safe direction) place the front lip of your mag into the weapon until you feel it catch, then rotate the mag to the rear until the mag catch locks the mag into place.
3. While holding the firearm in a safe direction and all fingers away from the trigger, loop your finger over the bolt handle and firmly pull to the rear of the weapon until it can't go any further and then release it.
4. You have now chambered a round. Place your safety lever to the upper most position.
5. When you are ready to fire and you are sure of your target and what's behind it, drop your safety lever to the lower most position.
6. Aim at your target and pull the trigger.
Please Note: Once the trigger is pulled, the bullet is going out of the barrel. Nothing will bring it back.
PLEASE BE SURE OF YOUR TARGET.
7. To unload your weapon, start by removing the loaded magazine. Then pull the bolt handle back and look into the chamber. A good habit would be to pull the bolt at least 2 times, just to be sure.